



ASCENDENT TECHNOLOGY GROUP

Quick Guide

ASC-540EX-PTZ36X Series PTZ and ASC-2X-ECON Controller

To access OSD Programming Menu:
Press 95, Call



Navigate up and down using the control stick.



To select a submenu press Open



To exit press Close



To activate the wiper:
Press 77, Call



To deactivate the wiper:
Press 78, Call



To access infrared illuminators:
Open OSD Menu (see above)
Navigate to "Aux" submenu
Choose On/Off for illumination

