



ASCENDENT
TECHNOLOGY GROUP

iPhone & Android Connection Guide

In the Apple App Store or the Android Market search "Ascendent"
You will see two apps as a result: "**ARMS**" & "**ARMS X4**"; both apps are free.

If you have an Ascendent **X4 PC Based DVR** you will need to download "**ARMS X4**"

If you have an Ascendent **X4S Standalone DVR** you will need to download "**ARMS**"

Once you have successfully downloaded the app for your Ascendent DVR, open it.

X4 PC Based DVRs: **ARMS X4**

Once the app is open on your device you will see the Server List. This list allows you to add multiple DVRs to your smartphone.

1. To add a DVR press the plus sign (+)
2. Enter a unique name for your DVR in "**Server's Name**"
3. Input your DVR's external IP address in "**Server's IP/URL**"
4. Input the Port of your DVR in "**Server's Port**"
5. Enter your **User Name** and **Password** in the following fields and press "**Save**"

You will now be able to see your DVR in the Server List. Select your DVR and click **Login**.

X4S Standalone DVRs: **ARMS**

Once the app is open on your device you will need to add a DVR by clicking on the gear icon to access the settings.

1. To add a DVR press **Edit**, then **Add**
2. Enter a unique name for your DVR in the first field
3. Input your DVR's external IP address
4. Input the Port your DVR is using
5. Enter your **User Name** and **Password** in the following fields and press "**OK**"

You will now be able to see your DVR in the Device List, click **Done**. To begin viewing the video press the play icon in the bottom left corner.